

DAMPNESS INSIDE THE CAR

When the car is parked out side of you home for 365 days of the year through all kinds of weather, the inside will become damp! Even in a garage that's not heated.

Buy a timer switch, and an extension cable, plus a hair dryer. Before you use the hair dryer make sure that it has variable speed controller, also make sure that the cut out switch works as well by doing this test cover the air intake at the back place your hand over it and hold it there until it cuts off it's known as a thermostatic cut off safety switch, after it has cooled down it should work again.

Place the dryer in a safe position and set it on slow speed running on the timer, like one hour on and two hours off, you will find out that this will keep the inside of your car free from dampness, and in the winter free from iced up doors and windows. Or you can buy one of those foot warmer heater's these work from the cigar lighter plug. But if you buy or have a small 12-volt transformer use this via the time switch from the mains.